


Service Manual

PIONEER®
The Art of Entertainment



ORDER NO.
RRV1025

STEREO AMPLIFIER

A-C5

A-C3

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	The voltage can be converted by the following method.
	A-C5	A-C3		
HEWZIW	○	○	AC220—230V	AC240V, *
HE	○	○	AC220—230V	AC240V, *
HB	○	○	AC240V	AC220—230V, *

* : Alter the wiring of the Power-supply block at the primary winding of Power-transformer referring to the "Line Voltage Selection" described in Service Manual.

• For the following: A-C5/HE and HB; A-C3/HEWZIW, HE and HB, refer to page 32.

CONTENTS

1. EXPLODED VIEWS, PACKING AND PARTS LIST	2
2. SCHEMATIC AND PCB CONNECTION DIAGRAMS	6
3. PCB PARTS LIST	27
4. BLOCK DIAGRAM	30
5. IC INFORMATION	31
6. FOR A-C5/HE, HB, A-C3/HEWZIW, HE AND HB TYPES	32
7. PANEL FACILITIES	36
8. SPECIFICATIONS	38

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan*1, 9120 Melsele, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
 © **PIONEER ELECTRONIC CORPORATION 1994**

T-FF JAN. 1994 Printed in Japan

1. EXPLODED VIEWS, PACKING AND PARTS LIST


NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.


• PARTS LIST

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
Δ	1	TRANSISTOR Q3,Q4	2SA1264N		51	FUNCTION BUTTON(PLS)	AAD7016
Δ	2	TRANSISTOR Q1,Q2	2SC3181N	NSP	52	HEAD PHONE ASSY	AWZ7001
Δ	3	TRANSISTOR Q5,Q6	2SC4137	NSP	53	TRANS CONNECT ASSY	AWZ7300
	4	SUB PANEL(PLS)	AMB7030		54	AF ASSY	AWZ7008
Δ	5	POWER TRANSFORMER	ATS7007		55	SUB TRANS ASSY	AWZ7023
	6	TERMINAL SCREW	AKE-031		56	VOLUME ASSY	AWZ7005
Δ	7	FU1001 (I=T1.6A,V=250)	AEK-510	NSP	57	SP OUT ASSY	AWZ7019
Δ	8	AC POWER CORD	ADG1049		58	POWER AMP ASSY	AWZ7029
	9	FLEXIBLE CABLE	ADD1128		59	FRONT ASSY	AWZ7031
	10	FLEXIBLE CABLE	ADD1130		60	FUNCTION ASSY	AWZ7033
NSP	11	CHASSIS	ANA7005	Δ	61	FU1003 (I=T800MA,V=250)	AEK-507
	12	REAR PANEL(MTL)	ANC7062		62	OPERATING INSTRUCTIONS (German, Italian)	ARC7004
NSP	13	HEAT SINK	ANH7003		63	REMOTE CONTROL UNIT	AXD7018
	14	INSULATOR	AMR7007	NSP	64	BATTERY(R6P,AA)	AEX-010
	15	INSULATOR	PNW2363		65	F.PAD	AHA7012
	16	KINK METAL	ANG1838		66	R.PAD	AHA7013
	17	PCB METAL	ANG7001		67	PACKING CASE	AHD7009
	18	SHIELD BOX	ANK7001		68	PACKING SHEET	AHG1093
	19	FRONT PANEL(AL)	ANB7004		69	BATTERY COVER	AZA7027
	20	CUSHON GUM	AEB7003		70	CUSHON GUM	AEB7005
	21	BONNET CASE(MTL)	ANE7015		71	FAN MOTOR	AXM1019
	22	SCREW	PTZ45P100FZK				
	23	STRAIN RELIEF	AEC-882				
	24	NYLON RIVET	AEC1160				
NSP	25	PCB SPACER	AEC1371				
NSP	26	PCB SUPPORT	AEC1461				
	27	SHEET	AEE1014				
	28	BINDER	AEP-215				
NSP	29	PCB MOULD	AMR2115				
	30	PCB HOLDER	AMR7008				
NSP	31	CORD CLAMPER	PEC-034				
	32	FRONT PANEL	AMB7045				
	33	SCREW (STEEL)	ABA1006				
	34	SCREW	ABA1024				
	35	SCREW	ABA1082				
	36	SCREW (STEEL)	ABA1095				
	37	SCREW (STEEL)	ABA1184				
	38	SCREW (STEEL)	ABA1192				
	39	SCREW (STEEL)	ABA1193				
	40	SCREW (STEEL)	ABA7002				
	41	SCREW	BBZ30P080FZK				
	42	SCREW	BBZ30P100FZK				
	43	SCREW	BPZ26P080FMC				
	44	LENS(POWER IND)	AAK2442				
	45	VOLUME LING	AAK7029				
	46	DISPLAY PANEL(PLS)	AAK7031				
	47	NAME PLATE (AL)	RAN1013				
	48	VOLUME ASSY(AL)	AAB7009				
	49	BASS TRE KNOB(PLS)	AAB7011				
	50	POWER BUTTON(PLS)	AAD7013				

• PACKING





● EXTERIOR



NOTE : Screws adjacent to ▼ mark on product are used for disassembly.

● HEAT SINK ASSY



2. SCHEMATIC AND PCB CONNECTION DIAGRAMS

NOTE FOR SCHEMATIC DIAGRAMS (Type 1A)

1. When ordering service parts, be sure to refer to "PARTS LIST of EXPLODED VIEWS" or "PCB PARTS LIST".

2. Since these are basic circuits, some parts of them or the values of some components may be changed for improvement.

3. RESISTORS:
Unit: k:kΩ, M:MΩ, or Ω unless otherwise noted.
Rated power: 1/4W, 1/6W, 1/8W, 1/10W unless otherwise noted.
Tolerance: (F): ±1%, (G): ±2%, (K): ±10%, (M): ±20% or ±5% unless otherwise noted.

4. CAPACITORS:
Unit: p:pF or μF unless otherwise noted.
Ratings: capacitor (μF)/ voltage (V) unless otherwise noted.
Rated voltage: 50V except for electrolytic capacitors.

5. COILS:
Unit: m:mH or μH unless otherwise noted.

6. VOLTAGE AND CURRENT:
V : Signal voltage at rated output.
or - V :
DC voltage (V) at no input signal unless otherwise noted.
Value in () is DC voltage at rated power.
mA or - mA :
DC current at no input signal unless otherwise noted.

7. OTHERS:
• or : Adjusting point.
• : Measurement point.
• The Δ mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.


8. SCH-□ ON THE SCHEMATIC DIAGRAM:
• SCH-□ indicates the drawing number of the schematic diagram. (SCH stands for schematic diagram.)


9. SWITCHES (Underline indicates switch position):
FRONT ASSY
S1901 : LOUDNESS
S1902 : TAPE2/AUX
S1903 : TAPE1
S1904 : CD
S1905 : TUNER
S1906 : PHONO
S1907 : DIRECT
S1908 : POWER

NOTE FOR PCB DIAGRAMS:
1. Part numbers in PCB diagrams match those in the schematic diagrams.
2. A comparison between main parts of PCB and schematic diagrams is shown below.



Symbol in PCB Diagrams	Symbol in Schematic Diagrams	Part Name
		Transistor
		Diode
		Capacitor (Polarized)

3. The transistor terminal marked with E or □ shows the emitter.
4. The diode terminal marked with ⊕ or C shows cathode side.
5. The capacitor terminal marked with ⊕ or L shows negative terminal.






HEWZIW TYPE ONLY



67

R2159
220 (HEWZI W TYPE)
47 (HE AND HB TYPES)

[illegible]

TO AF ASSY
CN2104 (-SCH-2)


**FUNCTION ASSY,
FRONT ASSY,
SP OUT ASSY**

FRONT ASSY


(AWZ7031: A-C5/HEWZIW)
 (AWZ7030: A-C5/HE AND A-C5/HB)
 (AWZ7038: A-C3/HEWZIW)
 (AWZ7037: A-C3/HE AND A-C3/HB)

→ : Signal route
 → : HEWZIW TYPE ONLY

SCH-3



SR
 +S.6V
 UP
 CND
 DOWN
 LOUDNESS ON/OFF
 POWER
 AC RY
 SP RY
 MUTE
 FAN ERR.
 BACK UP
 AC WAVE
 NC
 TO
 SUB
 TRANS
 ASSY
 CN1103
 (-SCH-2)



D1903-1909: AEL1144
 D1902, 1903, 1908-1914: XDC124EK

R1925
 2.2K (A-C5 SERIES)
 0 (A-C3 SERIES)




FUNCTION ASSY,
 FRONT ASSY,
 SP OUT ASSY

SCH-3



• This diagram is viewed from the foil side.

PCB-S



A

B

C

D

A



B

C

D

2.4 POWER AMP AND VOLUME ASSY


- This diagram is viewed from the foil side.

[illegible]


01201	01205 01206	01205	01204 01203
	01205	01201	

2.4 POWER AMP AND VOLUME ASSY

● This diagram is viewed from the mounted parts side.



Q1252	Q1222	Q1210	Q1204	Q1214	Q1224	Q1223	Q1213	Q1203	Q1209	Q5	Q1251
Q6	Q1202		Q1254			Q1253	Q3	Q1201	Q1221	Q1	
Q2			Q4								




SCH-4

POWER AMP ASSY (AWZ7029:A-C5/HEWZIW)
(AWZ7028:A-C5/HE AND A-C5/HB)
(AWZ7036:A-C3/HEWZIW)
(AWZ7035:A-C3/HE AND A-C3/HB)

Q1, Q2
2SC3181N (A-C5 SERIES)
2SC3180N (A-C3 SERIES)

Q3, Q4
2SA1264N (A-C5 SERIES)
2SA1263N (A-C3 SERIES)




TO AF ASSY
CN1204 (→SCH-2)

TO AF ASSY
CN1203 (→SCH-2)

- LOUDNESS L
- GND
- LOUDNESS R
- DIRECT/TONE IN L
- GND
- DIRECT/TONE IN R
- GND
- DIRECT/TONE OUT R
- GND
- DIRECT/TONE OUT L
- 12V
- +12V
- LOUDNESS CTRL
- MOTOR GND
- MOTOR +B
- UP
- DOWN
- MUTE

→: Signal route
* : HEWZIW TYPE ONLY

VOLUME ASSY
(AWZ7005:A-C5/HEWZIW)
(AWZ7004:A-C5/HE AND A-C5/HB)
(AWZ7013:A-C3/HEWZIW)
(AWZ7012:A-C3/HE AND A-C3/HB)



POWER AMP ASSY,
VOLUME ASSY

SCH-4

SCH-4

POWER AMP ASSY,
VOLUME ASSY

3. PCB PARTS LIST

NOTES:

- Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by “ $\odot$ ” are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.
Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ 56 $\times 10^1$ $\rightarrow$ 561 RD1/8PM $\boxed{561}J$
47k Ω $\rightarrow$ 47 $\times 10^3$ $\rightarrow$ 473 RD1/4PS $\boxed{473}J$
0.5 Ω $\rightarrow$ 0R5 RN2H $\boxed{0R5}K$
1 Ω $\rightarrow$ 010 RS1P $\boxed{010}K$


Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).
5.62k Ω $\rightarrow$ 562 $\times 10^1$ $\rightarrow$ 5621 RN1/4PC $\boxed{5621}F$

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
LIST OF ASSEMBLIES							
NSP	AMP AF ASSY		AWK7003	NSP	HEAD PHONE ASSY		AWZ7001
	TRANS CONNECT ASSY		AWZ7300		AF ASSY		AWZ7008
	SUB TRANS ASSY		AWZ7023		AMP FUKUGOU ASSY		AWM7001
	VOLUME ASSY		AWZ7005		SP OUT ASSY		AWZ7019
NSP	POWER AMP ASSY		AWZ7029	NSP	FRONT ASSY		AWZ7031
	FUNCTION ASSY		AWZ7033		Q5004—Q5007		XDC124ES
	D1253,D1254,D1256,D1257,D5004		HSS104—02		D5008,D5009		HSS104—02
	D1111		RBV602		D5007		RD5.6ESB1
	D1116		RD6.2ESB		D1112—D1115,D1255		S5566
	D5006		RD6.8ESB1		TH5001		NTH2218F
	D5005		RD9.1ESB1		COILS AND FILTERS		
	L1241,L1242 (0.7UH)		ATH1004		SWITCHES AND RELAYS		
	L1011—L1014		ATX1012		CAPACITORS		
	C1112 (10000/50V)		ACH1078		C1113 (2200/42V)		ACH1109
	C1111 (10000/50V)		ACH1196		C1122,C1123		CEANPR47M100
	C1252,C1272,C1273		CEAS010M50		C1261		CEAS100M50
	C1115—C1118		CEAS101M25		C1114		CEAS102M35
	C1119		CEAS222M16		C1120		CEAS471M6
	C1271		CEAS471M6		C1241—C1244		CFTYA104J50
	C2191—C2196		CKCYB391K50		RESISTORS		
	R1243,R1244		RD1/2PMF100J		R1256		RD1/4PM124J
	R1258		RD1/4PM243J		R1114		RD1/4PMF010J
	R1113,R1241,R1242		RD1/4PMF100J		R1259,R1260,R1275—R1278		RD1/8PM $\square\square\square J$
	R1255—R1258		RD1/4PMF101J		R1259,R1260,R1275—R1278		RD1/4PMF101J
	R1259,R1260,R1275—R1278		RD1/4PMF101J		R1259,R1260,R1275—R1278		RD1/4PMF101J
	R1259,R1260,R1275—R1278		RD1/4PMF101J		R1259,R1260,R1275—R1278		RD1/4PMF101J
	R1259,R1260,R1275—R1278		RD1/4PMF101J		R1259,R1260,R1275—R1278		RD1/4PMF101J

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	R1111,R1112		RS2LMFR22J		RESISTORS		
	Other Resistors		RD1/8PM $\square\square\square J$		R1523		RS1PMF821J
	VR1501		(50K)		ACX1090		ACX1090
	Other Resistors				RS1/10S $\square\square\square J$		RS1/10S $\square\square\square J$
OTHERS	SCREW		ABA—298		SP OUT ASSY		
	PIN JACK 4—P(TAPE2/AUX)		AKB1141		COILS AND FILTERS		
	JACK		AKN—207		L1281,L1282 (1UH)		ATH—133
	PCB BINDER		VEF1008		CAPACITORS		
	Q1101		XDC143ES		C1283,C1284		CQMA273J50
	D1103,D1104		HSS104—02		RESISTORS		
	D1101,D1102		S5566		R1281,R1282		RD1/2PMF101J
	COILS AND FILTERS				OTHERS		
Δ	L1001 (0.8/250V)		ATF—151		SPEAKER TERMINAL 4—P		AKE1013
	TRANSFORMERS				POWER AMP ASSY		
	Δ T1001 (1.6VA)		ATT1193		SEMICONDUCTORS		
	SWITCHES AND RELAYS				Q1209,Q1210		2SA1048
Δ	RY1001		ASR1027		Q1221,Q1222		2SA1145
	CAPACITORS				Q1253,Q1254		2SA965
	Δ C1001,C1002 (0.01/400V)		ACG1002		Q1201—Q1204		2SA992
	C1101 (0.01/150V)		ACG1005		Q1251,Q1252		2SC2235
	C1102		CEAS102M25		Q1213,Q1214		2SC2458
	C1103		CEAS4R7M50		Q1223,Q1224		2SC2705
	RESISTORS				D1213,D1214,D1221—D1224		HSS104—02
	R1101		RD1/2PM470J		D1229—D1232		HSS104—02
	R1103		RD1/4PM332J		D1225—D1228		HZS6A2L
	Other Resistors		RD1/8PM $\square\square\square J$		CAPACITORS		
	OTHERS				C1201,C1202 (2.2/50V)		ACH1251
	Δ CN1103		AKP1034		C1221,C1222 (4.7/10V)		ACH1252
	AC SOCKET 1—P		AKP1136		C1225,C1226		CCCSL050C500
	15P SOCKET				C1251—C1254		CCCSL101K500
	VOLUME ASSY				C1213,C1214,C1223,C1224		CCCSL270K500
	SEMICONDUCTORS				C1209—C1212		CCCSL470J50
	IC1501		M5220P		C1203,C1204		CCDSL221J50
	IC1502		TA8409S		C1231,C1232		CEAS010M50
	Q1503,Q1504		2SC2878		C1229,C1230		CEAS101M10
	Q1501,Q1502		2SK246		C1205,C1206		CKCYB222K50
	Q1505,Q1506		XDA124ES		C1215,C1216,C1227,C1228		CKCYB471K50
	D1501—D1504		HSS104—02		RESISTORS		
	COILS AND FILTERS				R1261,R1262 (0.33/5W)		ACN—139
	L1501,L1502		LAU220K		R1201,R1202		RD1/4PM561J
	CAPACITORS				R1203,R1204,R1223,R1224		RD1/4PM563J
	C1511,C1512,C1521		CCSQCH221J50		R1255—R1258		RD1/4PMF101J
	C1501,C1502		CCSQSL150J50		R1249,R1250		RD1/4PMF221J
	C1505,C1506,C1513,C1514		CEAS100M50	Δ	R1227,R1228		RD1/4PMF680J
	C1519,C1520		CEAS100M50		R1221,R1222		RD1/4PM392J
	C1518		CEAS470M35		R1229,R1230,R1251—R1254		RFA1/4PS101J
	C1503		CKSQYB103K50		R1213—R1216		RFA1/4PS391J
	C1516,C1517		CKSQYF473Z50		R1259,R1260,R1275—R1278		RFA1/4PS4R7J
	R1219,R1220		RD1/4PMF1601F		R1233,R1234		RD1/4PMF1601F
	R1233,R1234		RD1/4PM6200F		Other Resistors		RD1/8PM $\square\square\square J$
	Other Resistors				R1219,R1220		RD1/4PMF1601F
	R1233,R1234		RD1/4PM6200F		Other Resistors		RD1/8PM $\square\square\square J$

Mark No.	Description	Parts No.	Mark No.	Description	Parts No.
FRONT ASSY			COILS AND FILTERS		
SEMICONDUCTORS			L2101 - L2104		LAU221K
IC2401, IC2402		NJM4558M - D	CAPACITORS		
IC1901		PD6130A	C2137 - C2139		CCSQCH101J50
Q1902 - Q1905, Q1908 - Q1914		XDC124EK	C2119, C2120		CCSQCH151J50
Q1901, Q1906, Q1907		XDC143EK	C2155 - C2158		CCSQCH221J50
D1921		1SS181	C2145, C2146		CCSQCH390J50
			C2103 - C2116, C2123, C2124		CCSQCH391J50
D1916 - D1920		1SS184			
D1903 - D1909		AEL1144	C2101, C2102		CCSQCH470J50
D1902		AEL1148	C2163, C2164		CCSQL390J50
D1901, D1910, D1913		HSS104 - 02	C2117, C2118, C2131, C2132		CEAS100M50
D1912		RD5.1ESB	C2151 - C2154, C2159 - C2162		CEAS100M50
			C2171 - C2174		CEAS100M50
D1914, D1915		RD6.2ESB			
D1911		RD7.5ESB			
COILS AND FILTERS			C2133, C2134		CEAS101M25
L1901		LAU101K	C2165, C2166		CEAS470M25
SWITCHES AND RELAYS			C2121, C2122		CEAS471M6
S1901 - S1908		ASG1034	C2125, C2126		CFTXA243J50
CAPACITORS			C2127, C2128		CFTXA823J50
C1909		ACH1246			
C2423, C2424		CCSQCH181J50	C2142, C2143		CKCYX104M16
C2407, C2408, C2417, C2418		CEAS100M50	C2129, C2130		CKSQYB222K50
C2406, C2419, C2420		CEAS470M25	C2100		CKSQYF473Z50
C2401, C2402		CEJA100M16	C2167, C2168		CQMA273J50
			C2169, C2170		CQMA393J50
C1901, C1908		CEJA100M50	RESISTORS		
C1903, C2405		CEJA470M16	△ R2136, R2137		RD1/4PMF101J
C2409, C2410		CFTXA153J50	R2183 - R2188		RD1/4PMF101J
C2415, C2416		CFTXA183J50	R2143, R2144		RD1/8PM101J
C2411, C2412		CFTXA823J50	R2140 - R2142		RD1/8PM102J
			R2115, R2116		RD1/8PM122J
C1904		CKPUYF223Z25	Other Resistors		
C1902, C1905 - C1907, C1910 - C1916		CKSQYB103K50	OTHERS		
C2403, C2404, C2421, C2422		CKSQYB681K50	CN8509	PIN JACK(2P)(PHONO)	AKB1100
C2413, C2414		CQMA332J50	CN8508	PIN JACK(8P)	AKB1127
				(TAPE1, TUNER, CD)	
RESISTORS			CN2101	15P SOCKET	AKP1129
R2431, R2432		RD1/4PM390J		PCB BINDER	VEF1008
R1919		RD1/8PM102J			
R2421		RD1/8PM104J			
R2411		RD1/8PM154J			
R2418		RD1/8PM222J			
R2409, R2410		RD1/8PM223J			
R1921		RD1/8PM472J			
R2415		RD1/8PM683J			
VR2402, VR2403 (100K)		ACS1032			
VR2401		ACS1033			
Other Resistors					
		RS1/10S□□□J			
OTHERS					
CN1901, CN1902	15P SOCKET	AKP1130			
X1901	CERAMIC OSCILLATOR	ASS1022			
	REMOTE RECEIVER UNIT	AXX1033			
FUNCTION ASSY					
SEMICONDUCTORS					
IC2181		LC4966			
IC2161		NJM4558M - D			
IC2102		TC9163N			
IC2101, IC2153		UPC4570G2			
Q2183		XDA143ES			
Q2181, Q2182		XDC124ES			

4. BLOCK DIAGRAM




5. IC INFORMATION

- The information shown in the list is basic information and may not correspond exactly to that shown in the schematic diagrams.

■ PD6130A (IC1901)

● System control microcomputer

● Pin Assignment



● Pin Function

I : CMOS input UN : Nch open drain output with pull up

O : CMOS Out N : Nch open drain output

HI : Hysteresis input

NO.	Name	I/O	Function	PORT
1	AVCC	—	Pull up	—
2	RST	HI/UN	Reset	Input
3	MOD0	I	CONNECT to VSS	
4	MOD1	I		
5	X0	—	OSCILLATOR	—
6	X1	—		
7	VCC	—	+5V POWER SUPPLY	—
8	X0A	—	NC	—
9	X1A	—	GND	—
10	P27	O	LOUDNESS ON/OFF	
11	P26	O	DIRECT ON/OFF	
12	P25	O	LED TAPE2	
13	P24	O	TAPE1	
14	P23	O	CD	
15	P22	O	TUNER	
16	P21	O	PHONO	
17	P20	O	POWER	
18	P17	I/O	MAIN UNIT key LOUDNESS	Input
19	VSS	—	GND	—
20	P16	I/O	MAIN UNIT key TAPE2	Input
21	P15	I/O	PHONO	Input
22	P14	I/O	CD	Input
23	P13	I/O	TUNER	Input
24	P12	I/O	TAPE1	Input

NO.	Name	I/O	Function	PORT
25	P11	I/O	DIRECT	Input
26	P10	I/O	POWER	Input
27	P07	I/O	NC	Out
28	P06	I/O	NC	Out
29	P05	I/O	VOLUME UP (TA8409)	Out
30	P04	I/O	VOLUME DOWN	Out
31	P03	I/O	AC RLY	Out
32	P02	I/O	SP RLY	Out
33	P01	I/O	MUTE	Out
34	P00	I/O	REMOCON SIGNAL	Input
35	P37/BZ	HI/O	FAN. ERROR	Input
36	P36/INT2	HI/O	SILENT	Input
37	P35/INT1	HI/O	BACKUP	Input
38	P34/TO/INT0	HI/O	AC	Input
39	P33/EC/SCO	HI/O	NC	Out
40	P32/SI	HI/O	SIO STB	Out
41	P31/S0	HI/O	DATA	Out
42	P30/SCK	HI/O	CLOCK	Out
43	AVSS	—	NC	—
44	AVR	—	NC	—
45	P43/AN3	N	NC	
46	P42/AN2	N	NC	
47	P41/AN1	N	NC	
48	P40/AN0	N	NC	

6. FOR A—C5/HE, HB, A—C3/HEWZIW, HE AND HB TYPES

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

A—C5/HE, HB, A—C3/HEWZIW, HE, HB and A—C5/HEWZIW have the same construction except for the following:

Mark	Symbol & Description	Part No.						Remarks
		A—C5			A—C3			
		HEWZIW	HE	HB	HEWZIW	HE	HB	
NSP	AMP AF assembly	AWK7003	AWK7002	AWK7001	AWK7025	AWK7024	AWK7023	
	HEAD PHONE assembly	AWZ7001	AWZ7000	AWZ7000	AWZ7010	AWZ7181	AWZ7181	
	TRANS CONNECT assembly	AWZ7300	AWZ7299	AWZ7299	AWZ7003	AWZ7011	AWZ7011	
	AF assembly	AWZ7008	AWZ7007	AWZ7007	AWZ7016	AWZ7015	AWZ7015	
	SUB TRANS assembly	AWZ7023	AWZ7022	AWZ7021	AWZ7023	AWZ7022	AWZ7021	
NSP	AMP FUKUGOU assembly	AWM7001	AWM7094	AWM7094	AWM7003	AWM7002	AWM7002	
	VOLUME assembly	AWZ7005	AWZ7004	AWZ7004	AWZ7013	AWZ7012	AWZ7012	
	SP OUT assembly	AWZ7019	AWZ7277	AWZ7277	AWZ7034	AWZ7193	AWZ7193	
	POWER AMP assembly	AWZ7029	AWZ7028	AWZ7028	AWZ7036	AWZ7035	AWZ7035	
	FRONT assembly	AWZ7031	AWZ7030	AWZ7030	AWZ7038	AWZ7037	AWZ7037	
	FUNCTION assembly	AWZ7033	AWZ7032	AWZ7032	AWZ7039	AWZ7032	AWZ7032	
△	Power transformer (T8005)	ATS7007	ATS7007	ATS7007	ATS7005	ATS7005	ATS7005	
△	AC power cord	ADG1049	ADG1049	ADG1144	ADG1049	ADG1049	ADG1144	
△	Fuse (T1.6A/250V, FU1001)	AEK—510	AEK—510	AEK—510				
△	Fuse (T800mA/250V, FU1001)				AEK—507	AEK—507	AEK—507	
△	Transistor (Q3, Q4)	2SA1264N	2SA1264N	2SA1264N	2SA1263N	2SA1263N	2SA1263N	
NSP	Transistor (Q1, Q2)	2SC3181N	2SC3181N	2SC3181N	2SC3180N	2SC3180N	2SC3180N	
	Fan motor	AXM1019	AXM1019	AXM1019				
	Flexible cable	AAD1130	AAD1130	AAD1130	AAD1129	AAD1129	AAD1129	
	Heat sink	ANH7003	ANH7003	ANH7003	ANH7002	ANH7002	ANH7002	
	Front panel	AMB7045	AMB7045	AMB7045	AMB7046	AMB7046	AMB7046	
	Rear panel	ANC7062	ANC7062	ANC7062	ANC7067	ANC7067	ANC7067	
	Chassis cover				AMR7009	AMR7009	AMR7009	
	Volume assy	AAB7009	AAB7009	AAB7009				
	Volume button				AAB7010	AAB7010	AAB7010	
	Power button	AAD7013	AAD7013	AAD7013	AAD7014	AAD7014	AAD7014	
	Screw	BPZ45P100FZK	BPZ45P100FZK	BPZ45P100FZK				
	Screw				ABA1101	ABA1101	ABA1101	
	Binder			AEC—093			AEC—093	
	Packing case	AHD7009	AHD7009	AHD7009	AHD7012	AHD7012	AHD7012	
Operating instructions (German, Italian)	ARC7004			ARC7004				

Note; * : Refer to page 4.

Mark	Symbol & Description	Part No.						Remarks
		A—C5			A—C3			
		HEWZIW	HE	HB	HEWZIW	HE	HB	
	Operating instructions (English, French, German, Italian, Dutch, Swedish, Spanish, Portuguese)		ARE7009			ARE7009		
	Operating instructions (English)			ARB7004			ARB7004	

HEAD PHONE ASSEMBLY

● Although AWZ7000, AWZ7010, AWZ7181 and AWZ7001 are different in part number, they consist of the same components.

TRANS CONNECT ASSEMBLY

AWZ7299, AWZ7003, AWZ7011 and AWZ7300 have the same construction except for the following:

Mark	Symbol & Description	Part No.				Remarks
		AWZ7300	AWZ7299	AWZ7003	AWZ7011	
	C1124 (0.01/150V)	ACG1005		ACG1005		
	R999	RD1/4PMF4R7J	RD1/4PMF4R7J	RD1/4PMF4R7J		

AF ASSEMBLY

AWZ7007, AWZ7016, AWZ7015 and AWZ7008 have the same construction except for the following:

Mark	Symbol & Description	Part No.				Remarks
		AWZ7008	AWZ7007	AWZ7016	AWZ7015	
	IC5001	NJM4558DXP	NJM4558DXP			
	Q5001 - Q5003	XDA124ES	XDA124ES			
	Q5004 - Q5007	XDC124ES	XDC124ES			
	D1111	RBV602	RBV602	D3SBA20(A)	D3SBA20(A)	
	D5004, D5008, D5009	HSS104-02	HSS104-02			
	D5005	RD9.1ESB1	RD9.1ESB1			
	D5006	RD6.8ESB1	RD6.8ESB1			
	D5007	RD5.6ESB1	RD5.6ESB1			
	TH5001	NTH2218F	NTH2218F			
	C1111 (10000μ/50V)	ACH1196	ACH1196			
	C1111, C1112 (5600μ/50V)			ACH1145	ACH1145	
	C1112 (10000μ/50V)	ACH1078	ACH1078			
	C1113 (2200μ/42V)	ACH1109	ACH1109			
	C1113			CEAS102M35	CEAS102M35	
	C1114	CEAS102M35	CEAS102M35	CEAS471M35	CEAS471M35	
	C2191 - C2196	CKCYB391K50		CKCYB391K50		

Mark	Symbol & Description	Part No.				Remarks
		AWZ7008	AWZ7007	AWZ7016	AWZ7015	
	R1113	RD1/4PMF100J	RD1/4PMF100J	RD1/4PMF010J	RD1/4PMF010J	
	R1261	RD1/8PM432J	RD1/8PM432J	RD1/8PM152J	RD1/8PM152J	
	R1295,R1296	RD1/8PM222J	RD1/8PM102J	RD1/8PM222J	RD1/8PM102J	
	R5005	RD1/8PM472J	RD1/8PM472J			
	R5007—R5010,R5012	RD1/8PM103J	RD1/8PM103J			
	R5011	RD1/8PM241J	RD1/8PM241J			
	L1014	ATX1012	ATX1012			
	PCB Binder	VEF1008	VEF1008			

SUB TRANS ASSEMBLY

AWZ7022, AWZ7021 and AWZ7023 have the same construction except for the following:

Mark	Symbol & Description	Part No.			Remarks
		AWZ7023	AWZ7022	AWZ7021	
△	AC Socket (1P)	AKP1034	AKP1034	AKP1035	

VOLUME ASSEMBLY

AWZ7004, AWZ7013, AWZ7012 and AWZ7005 have the same construction except for the following:

Mark	Symbol & Description	Part No.				Remarks
		AWZ7005	AWZ7004	AWZ7013	AWZ7012	
	IC1501	M5220P	M5220P	UPC4570C	UPC4570C	
	C1511,C1512,C1521	CCSQCH221J50		CCSQCH221J50		
	VR1501	ACX1090	ACX1090	ACX1091	ACX1091	
	R1507,R1508	RS1/10S132J	RS1/10S132J	RS1/10S112J	RS1/10S112J	
	R1523	RS1PMF821J	RS1PMF821J			

SP OUT ASSEMBLY

AWZ7277, AWZ7034, AWZ7193 and AWZ7019 have the same construction except for the following:

Mark	Symbol & Description	Part No.				Remarks
		AWZ7019	AWZ7277	AWZ7034	AWZ7193	
	L1281,L1282	ATH—133		ATH—133		
	C1283,C1284	CQMA273J50		CQMA273J50		
	R1281,R1282	RD1/2PMF101J		RD1/2PMF101J		

POWER AMP ASSEMBLY

AWZ7028, AWZ7036, AWZ7035 and AWZ7029 have the same construction except for the following:

Mark	Symbol & Description	Part No.				Remarks
		AWZ7029	AWZ7028	AWZ7036	AWZ7035	
	C1203,C1204 C1215,C1216,1227,C1228	CCDSL221J50 CKCYB471K50		CCDSL221J50 CKCYB471K50		

FRONT ASSEMBLY

AWZ7030, AWZ7038, AWZ7037 and AWZ7031 have the same construction except for the following:

Mark	Symbol & Description	Part No.				Remarks
		AWZ7031	AWZ7030	AWZ7038	AWZ7037	
	Q1906	XDC143EK	XDC143EK			
	D1915	RD6.2ESB	RD6.2ESB			
	C1907 C1908	CKSQYB103K50 CEJA100M50	CKSQYB103K50 CEJA100M50			
	R1925	RS1/10S222J	RS1/10S222J	RS1/10S000J	RS1/10S000J	


FUNCTION ASSEMBLY

AWZ7032 and AWZ7033 have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		AWZ7033	AWZ7032	
	L2101 -L2104	LAU221K		
	C2101,C2102	CCSQCH470J50		
	C2103 -C2116,C2123,C2124	CCSQCH391J50		
	C2129,C2130	CKSQYB222K50		
	C2145,C2146	CCSQCH390J50		
	C2157,C2158	CCSQCH221J50		
	R2105,R2106	RS1/10S222J	RS1/10S102J	
	R2115,R2116	RD1/8PM122J		
	R2121,R2122	RD1/10S000J	RS1/10S181J	
	R2159,R2160	RD1/10S221J	RS1/10S470J	
	R2189,R2190	RD1/10S471J	RS1/10S000J	

●Although AWZ7039 and AWZ7033 are different in part number, they consist of the same components.

7. PANEL FACILITIES



① Loudness button

When listening at low sound levels, press this button to boost low and high ranges, giving the overall sound a greater impact. When ON, the button indicator lamp lights. Normally, leave in the OFF position.

② Remote control signal sensor

③ Tape 2/AUX monitor button

Set to ON when playing a second tape deck or other component (DAT, etc.).

④ Input selector buttons

Use to select the component to be played. The indicator lamp of the selected component will light.

⑤ Direct button

When this button is pressed ON, sound from the selected component will be played back without being processed through the tone and balance controls. When ON, the button indicator lamp lights.

⑥ Power switch / standby indicator

This is the switch for electric power.

on: When set to the on position, power is supplied and the unit becomes operational.

Standby: When set to the standby position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness.

When the standby indicator lights, the unit is in **STANDBY**.

⑦ Headphone jack

Use to connect headphones for private listening. When headphones are connected, sound to speakers is disconnected.

⑧ Volume control

⑨ Bass tone control knob

Use to adjust the bass tone. The center position is the default position. When the knob is rotated to the right, bass frequencies are boosted, and when rotated to the left, the bass frequencies are diminished.

- This control does not operate when the direct button is ON.

⑩ Treble tone control knob

Use to adjust the treble tone. The center position is the default position. When the knob is rotated to the right, treble frequencies are boosted, and when rotated to the left, the treble frequencies are diminished.


- This control does not operate when the direct button is ON.

⑪ Balance control knob

Use to adjust the right-left speaker balance. Rotate the knob to the right to increase the sound from the right speaker while diminishing the sound from the left speaker. Rotate the knob to the left to increase the sound from the left speaker while diminishing the sound from the right speaker.

- This control does not operate when the direct button is ON.

REMOTE CONTROL UNIT OPERATION



A. Amplifier operation buttons

- Function buttons:** Operate the same as the input selector buttons on the main unit.
- Power button:** Use to switch the amplifier's power between on and standby.
- Volume buttons:** Use to adjust the volume level.

B. Tuner (F-C5RDS/F-C3) operation buttons (U.K. model only)

- Station buttons:** Use to call out broadcast stations.

C. CD Player (PD-C5/PD-C3) operation buttons (U.K. model only)

- Stop button:** Press to stop playback.
- Play button:** Press to begin play.
- Track search buttons:**
- ◀◀: When this button is pressed, play returns to the beginning of the currently playing track; when pressed repeatedly, play returns to previous tracks.
 - ▶▶: When this button is pressed, play advances to the beginning of the next track; when pressed repeatedly, play advances to subsequent tracks.
- Time button:** When this button is pressed, The CD player's display section switches as follows:

Elapsed time of currently playing track → Remaining time of currently playing track (not displayed for tracks 30 and above)

↑ ↓

Total time and total number of tracks on disk. ← Remaining time on disc (or programmed tracks); does not display during random playback

● "AL" is displayed.


- PGM button:** Use to program disc tracks in any desired order of playback.
- RND button:** Random button: When this button is pressed, the CD player plays back all tracks on the disc in random order. When pressed during program playback, the program is canceled and random playback begins.
- Edit button:** Used for auto program edit (see page 12).

D. Tape deck (T-C3) operation buttons (U.K. model only)


- Playback buttons:** Press to begin playback in the indicated direction.
- Stop button:** Press to stop tape travel.
- Fast forward buttons:** Press to fast forward the tape in the indicated direction. These buttons can also be used to perform music search (see tape deck's Operating Instructions).
- Recording muting button:** When this button is pressed, a four-second non-recorded interval is created, after which the tape deck enters the recording standby mode. When held depressed, a non-recorded interval is created for as long as the button is held depressed.
- Pause button:** Press to pause playback or recording. Press again to resume playback or recording.
- Recording button:** Press to set to the recording mode; then, press the play button to begin recording.

This unit's remote control unit can be used in one of the two following ways:

1. To operate the component itself



2. When this component is connected by system control cables to other Pioneer components (F-C5RDS/F-C3, T-C3, PD-C5/PD-C3), the remote control unit can be used for central system control.
(Aim the remote control unit at the amplifier's signal receiver to control all components.)



8. SPECIFICATIONS

Amplifier Section

Continuous Average Power Output is 40 watts* (A-C5) per channel, min., at 8 ohms from 20 Hertz to 20,000 Hertz with no more than 0.07 % total harmonic distortion.**

Continuous power output (DIN)

(both channels driven at 1 kHz)

A-C5 67 W + 67 W (T.H.D. 1 %, 4 Ω)
45 W + 45 W (T.H.D. 1 %, 8 Ω)

A-C3 35 W + 35 W (T.H.D. 1 %, 8 Ω)

Continuous power output **

(both channels driven, direct switch ON):

A-C5 40 W + 40 W (T.H.D. 0.07%, 20 Hz to 20 kHz, 8 Ω)

A-C3 30 W + 30 W (T.H.D. 0.07%, 20 Hz to 20 kHz, 8 Ω)

Continuous power output (RMS)

A-C5 60 W + 60 W (1 kHz, T.H.D. 10%, 8 Ω)

A-C3 45 W + 45 W (1 kHz, T.H.D. 10%, 8 Ω)

Input connectors (sensitivity/input impedance):

PHONO MM 2.8 mV/47 k Ω

CD, TUNER, TAPE 1, etc. 200 mV/47 k Ω

Output terminals (output level, impedance):

TAPE 1 REC, TAPE 2 AUX REC 200 mV/1 k Ω

Frequency response:

PHONO (MM) 20 Hz-20 kHz $\pm$ 0.3 dB

CD, TUNER, TAPE 1, etc. 2 Hz-160 kHz, $^{+0}_{-3}$ dB
(Direct switch ON)

Tone controls (at -30 dB):

BASS $\pm$ 9 dB (100 Hz)

TREBLE $\pm$ 9 dB (10 kHz)

Loudness control: (at -30 dB) 100 Hz/10 kHz (6 dB/4 dB)

S/N ratio (IHFA network, short circuit, Direct switch ON):

PHONO (MM) 85 dB

CD, TUNER, TAPE 1, etc. 105 dB

S/N ratio (DIN, continuous power/50 mW)

PHONO (MM) 69 dB/68 dB

CD, TUNER, TAPE 1, etc. 95 dB/73 dB

Power section, other

Power requirements:

U.S. model AC 120 V, 60 Hz

U.K. model AC 240 V, 50/60 Hz

Power consumption:

U.S. model 130 W (A-C5)

U.K. model 350 W (A-C5)

210 W (A-C3)

AC outlet unswitched: 1 (100 W)

External dimensions (W x H x D):

A-C5 (U.S. model) 260 x 110 x 358 mm

10-1/4 (W) x 4-5/16 (H) x 13-7/8 (D) in.

A-C5 (U.K. model) 260 x 110 x 353 mm

A-C3 260 x 110 x 353 mm

Weight:

A-C5 6.3 kg (13 lb, 14 oz)

A-C3 4.9 kg

Accessories

- Operating Instructions 1
- Warranty card 1
- Remote control unit 1
- AA Batteries (R6 / UM-3) 2

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifier

** Measured with audio spectrum analyzer.

NOTE:

Specifications and design subject to possible modifications without notice due to improvements.

Service Manual

ORDER NO.
RRV1375

STEREO AMPLIFIER

A-C5 A-C3

- Refer to the service manual RRV1025 for A-C5/HEWZIW.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	The voltage can be converted by the following method.
	A-C5	A-C3		
HEWZIW8	O	O	AC220-230V	AC240V, *
HE8	O	O	AC220-230V	AC240V, *

* : Alter the wiring of the Power-supply block at the primary winding of Power-transformer referring to the "Line Voltage Selection" described in Service Manual.

PIONEER ELECTRONIC CORPORATION

4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

PIONEER ELECTRONICS SERVICE, INC. P.O.Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 501 Orchard Road, #10-00 Lane Crawford Place, Singapore 0923

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω	$\rightarrow$	56×10^1	$\rightarrow$	561	RD1/8PM	561J
47k Ω	$\rightarrow$	47×10^3	$\rightarrow$	473	RD1/4PS	473J
0.5 Ω	$\rightarrow$	0R5			RN2H	0R5K
1 Ω	$\rightarrow$	010			RS1P	010K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω	$\rightarrow$	562×10^1	$\rightarrow$	5621	RN1/4PC	5621F
----------------	---------------	-------------------	---------------	------	---------	-------

1. CONTRAST OF A-C5/HEWZI8 AND A-C5/HEWZI

Although A-C5/HEWZI8 and A-C5/HEWZI are different in model name, they consist of the same components.

2. CONTRAST OF A-C5/HE8 AND A-C5/HE

A-C5/HE8 and A-C5/HE have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		A-C5/HE	A-C5/HE8	
NSP	AMP AF ASSY	AWK7002	AWK7003 *	
NSP	— HEAD PHONE ASSY	AWZ7000	AWZ7001 *	
	— TRANS CONNECT ASSY	AWZ7299	AWZ7300 *	
	— AF ASSY	AWZ7007	AWZ7008 *	
	— SUB TRANS ASSY	AWZ7022	AWZ7023 *	
NSP	AMP FUKUGOU ASSY	AWM7094	AWM7001 *	
	— VOLUME ASSY	AWZ7004	AWZ7005 *	
	— SP OUT ASSY	AWZ7277	AWZ7019 *	
	— POWER AMP ASSY	AWZ7028	AWZ7029 *	
	— FRONT ASSY	AWZ7030	AWZ7031 *	
	— FUNCTION ASSY	AWZ7032	AWZ7033 *	

Note : Parts marked * are the same as those of A-C5/HEWZI8 which is shown with A-C5/HEWZI8 in the service manual RRV1025.

3. CONTRAST OF A-C3/HEWZI8 AND A-C3/HEWZI

Although A-C3/HEWZI8 and A-C3/HEWZI are different in model name, they consist of the same components.

4. CONTRAST OF A-C3/HE8 AND A-C3/HE

A-C3/HE8 and A-C3/HE have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		A-C3/HE	A-C3/HE8	
NSP	AMP AF ASSY	AWK7024	AWK7025 *	
NSP	— HEAD PHONE ASSY	AWZ7181	AWZ7010 *	
	— TRANS CONNECT ASSY	AWZ7011	AWZ7003 *	
	— AF ASSY	AWZ7015	AWZ7016 *	
	— SUB TRANS ASSY	AWZ7022	AWZ7023 *	
NSP	AMP FUKUGOU ASSY	AWM7002	AWM7003 *	
	— VOLUME ASSY	AWZ7012	AWZ7013 *	
	— SP OUT ASSY	AWZ7193	AWZ7034 *	
	— POWER AMP ASSY	AWZ7035	AWZ7036 *	
	— FRONT ASSY	AWZ7037	AWZ7038 *	
	— FUNCTION ASSY	AWZ7032	AWZ7039 *	

Note : Parts marked * are the same as those of A-C3/HEWZI8 which is shown with A-C3/HEWZI8 in the service manual RRV1025.

Service Manual

ORDER NO.
RRV1 3 7 5

STEREO AMPLIFIER

A-C5 A-C3

- Refer to the service manual RRV1025 for A-C5/HEWZIW.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	The voltage can be converted by the following method.
	A-C5	A-C3		
HEWZIW8	O	O	AC220-230V	AC240V, *
HE8	O	O	AC220-230V	AC240V, *

* : Alter the wiring of the Power-supply block at the primary winding of Power-transformer referring to the "Line Voltage Selection" described in Service Manual.

PIONEER ELECTRONIC CORPORATION

4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

PIONEER ELECTRONICS SERVICE, INC. P.O.Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 501 Orchard Road, #10-00 Lane Crawford Place, Singapore 0923

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω	$\rightarrow$	56×10^1	$\rightarrow$	561	RD1/8PM567J
47k Ω	$\rightarrow$	47×10^3	$\rightarrow$	473	RD1/4PS473J
0.5 Ω	$\rightarrow$	0R5			RN2H0R5K
1 Ω	$\rightarrow$	010			RS1P010K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω	$\rightarrow$	562×10^1	$\rightarrow$	5621	RN1/4PC5621F
----------------	---------------	-------------------	---------------	------------	--------------

1. CONTRAST OF A-C5/HEWZIW8 AND A-C5/HEWZIW

Although A-C5/HEWZIW8 and A-C5/HEWZIW are different in model name, they consist of the same components.

2. CONTRAST OF A-C5/HE8 AND A-C5/HE

A-C5/HE8 and A-C5/HE have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		A-C5/HE	A-C5/HE8	
NSP	AMP AF ASSY	AWK7002	AWK7003 *	
NSP	— HEAD PHONE ASSY	AWZ7000	AWZ7001 *	
NSP	— TRANS CONNECT ASSY	AWZ7299	AWZ7300 *	
NSP	— AF ASSY	AWZ7007	AWZ7008 *	
NSP	— SUB TRANS ASSY	AWZ7022	AWZ7023 *	
NSP	AMP FUKUGOU ASSY	AWM7094	AWM7001 *	
NSP	— VOLUME ASSY	AWZ7004	AWZ7005 *	
NSP	— SP OUT ASSY	AWZ7277	AWZ7019 *	
NSP	— POWER AMP ASSY	AWZ7028	AWZ7029 *	
NSP	— FRONT ASSY	AWZ7030	AWZ7031 *	
NSP	— FUNCTION ASSY	AWZ7032	AWZ7033 *	

Note : Parts marked * are the same as those of A-C5/HEWZIW which is shown with A-C5/HEWZIW in the service manual RRV1025.

3. CONTRAST OF A-C3/HEWZIW8 AND A-C3/HEWZIW

Although A-C3/HEWZIW8 and A-C3/HEWZIW are different in model name, they consist of the same components.

4. CONTRAST OF A-C3/HE8 AND A-C3/HE

A-C3/HE8 and A-C3/HE have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		A-C3/HE	A-C3/HE8	
NSP	AMP AF ASSY	AWK7024	AWK7025 *	
NSP	— HEAD PHONE ASSY	AWZ7181	AWZ7010 *	
NSP	— TRANS CONNECT ASSY	AWZ7011	AWZ7003 *	
NSP	— AF ASSY	AWZ7015	AWZ7016 *	
NSP	— SUB TRANS ASSY	AWZ7022	AWZ7023 *	
NSP	AMP FUKUGOU ASSY	AWM7002	AWM7003 *	
NSP	— VOLUME ASSY	AWZ7012	AWZ7013 *	
NSP	— SP OUT ASSY	AWZ7193	AWZ7034 *	
NSP	— POWER AMP ASSY	AWZ7035	AWZ7036 *	
NSP	— FRONT ASSY	AWZ7037	AWZ7038 *	
NSP	— FUNCTION ASSY	AWZ7032	AWZ7039 *	

Note : Parts marked * are the same as those of A-C3/HEWZIW which is shown with A-C3/HEWZIW in the service manual RRV1025.

P.S

1. Sub trans assy (AWZ7023) is made a design change like the following:

Mark	Description	OLD	NEW
△	C1001, C1002	ACG1002 (0.01μF/400V)	ACG7020 (0.01μF/250V)

2. Function assy (AWZ7033, AWZ7039) is made a design change like the following:

Mark	Description	OLD	NEW
	C2137 – C2139 C2136	CCSQCH101J50 Not used	Not used CKCYF473Z50